ASSEMBLY INSTRUCTIONS

B6910/B6912/B6918-Q-HBFB and B6910/B6912/B6918-KQ-RAIL AMALIA QUEEN BED CRWN

(DOV 1) DOV OF OLIFEN HE ADDOADD/FOOTDOADD									
(BOX 1) - BOX OF QUEEN HEADBOARD/FOOTBOARD									
PARTS LIST				HARDWARE LIST					
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	QTY		
1	HEADBOARD PANEL		1	A	JCBB (M8 x 40mm) W/FLAT WASHER & SPRING WASHER	200	6		
2	HEADBOARD LEG (L/R)		2	В	JCBB (M8 x 20mm) W/FLAT WASHER	2	8		
3	FOOTBOARD		1	С	ALLEN KEY (M5)		1		
4	SLAT		4	D	PANHEAD (M4 x 32mm)		8		
5	VERTICAL LEG		4	Е	SCREW DRIVER (*)		1		

*The manufacturer does not provide item E.

(BOX 2) - BOX OF KING / QUEEN SIDE RAIL									
PARTS LIST									
NO.	DESCRIPTION	SKETCH	QTY						
6	SIDE RAIL		2						

IMPORTANT NOTE:

- * Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- * Check to be sure that you have all parts and hardware.
- * Remove all wrapping materials, including staples & packing straps before you start to assemble.
- * Do not tighten all screws/bolts until all completely assembled.
- * Keep all hardware parts out of reach of children.

